

Versa LASER™

Models VLS2.30 & VLS3.50

Safety, Installation, Operation,
and Basic Maintenance Manual

System Serial Number: _____

(Located on the back of the machine)

Universal Laser Systems, Inc.

16008 North 81st Street

Scottsdale, AZ 85260 USA

Technical Support Department

Phone: 480-609-0297

Fax: 480-609-1203

Web Based Email Support: www.ulsinc.com/VersaLASER/

April 2007

CE

Notice

This publication and its contents are proprietary to Universal Laser Systems, Inc. (ULS), and are intended solely for the contractual use of ULS, Inc. customers.

While reasonable efforts have been made to assure the accuracy of this manual, ULS shall not be liable for errors contained herein or for incidental or consequential damage in connection with the furnishing, performance, or use of this material. ULS reserves the right to revise this manual and make changes from time to time without obligation by ULS to notify any person of such revision or changes.

ULS does not assume any liability arising out of the application or use of any products, circuits, or software described herein. Neither does it convey a license under its patent rights nor the patent rights of others.

This publication and its contents may not be reproduced, copied, transmitted, or distributed in any form, or by any means, radio, electronic, mechanical, photocopying, scanning, facsimile, or otherwise, or for any other purpose, without the prior written permission of ULS.

ULS provides no warranties whatsoever on any software used in connection with a ULS Laser Engraving System, express or implied. Neither does it guarantee software compatibility with any off-the-shelf software package or any software program that has not been written by ULS.

Intended use of this system must be followed within the guidelines of this manual. In no event will ULS be liable for any damages caused, in whole or in part, by customer, or for any economic loss, physical injury, lost revenue, lost profits, lost savings or other indirect, incidental, special or consequential damages incurred by any person, even if ULS has been advised of the possibility of such damages or claims.

WARNING: UNIVERSAL LASER SYSTEMS PRODUCTS ARE NOT DESIGNED, TESTED, INTENDED OR AUTHORIZED FOR USE IN ANY MEDICAL APPLICATIONS, SURGICAL APPLICATIONS, MEDICAL DEVICE MANUFACTURING, OR ANY SIMILAR PROCEDURE OR PROCESS REQUIRING APPROVAL, TESTING, OR CERTIFICATION BY THE UNITED STATES FOOD AND DRUG ADMINISTRATION OR OTHER SIMILAR GOVERNMENTAL ENTITIES. SHOULD THE BUYER USE UNIVERSAL LASER SYSTEMS PRODUCTS FOR ANY SUCH UNINTENDED OR UNAUTHORIZED APPLICATION, ALL WARRANTIES REGARDING THE UNIVERSAL LASER SYSTEMS PRODUCTS SHALL BE NULL AND VOID. FURTHER, THE BUYER SHALL HAVE NO REMEDY AGAINST UNIVERSAL LASER SYSTEMS AND ITS OFFICERS, EMPLOYEES, SUBSIDIARIES, AFFILIATES AND DISTRIBUTORS FOR, AND THE BUYER SHALL INDEMNIFY AND HOLD THOSE PARTIES HARMLESS AGAINST, ANY AND ALL CLAIMS, COSTS, DAMAGES, EXPENSES AND REASONABLE ATTORNEY FEES ARISING OUT OF, DIRECTLY OR INDIRECTLY, ANY CLAIM ASSOCIATED WITH SUCH UNINTENDED OR UNAUTHORIZED USE, INCLUDING BUT NOT LIMITED TO ANY CLAIM BASED ON WARRANTY (EXPRESS OR IMPLIED), CONTRACT, TORT (INCLUDING ACTIVE, PASSIVE, OR IMPUTED NEGLIGENCE), STRICT LIABILITY, PATENT OR COPYRIGHT INFRINGEMENT OR MISAPPROPRIATION OF INTELLECTUAL PROPERTY.

HP is a registered trademark of Hewlett-Packard Corporation.

Windows is a registered trademark of Microsoft Corporation.

Macintosh is a registered trademark of Apple Computer Corporation.

PostScript, Photoshop, and Streamline are registered trademarks of Adobe Systems Inc.

CorelDRAW is a registered trademark of Corel Corporation.

AutoCAD is a registered trademark of AutoDesk Inc.

ULS Platforms are protected under one or more of U.S. patents 5,661,746; 5,754,575; 5,867,517; 5,881,087; 5,894,493; 5,901,167; 5,982,803; 6,181,719; 6,313,433; 6,342,687; 6,423,925; 6,424,670; 6,983,001; D517,474; 7,060,934. Other U.S. and International patents pending.

**© Universal Laser Systems Inc., 2007
All Rights Reserved**

Introduction

All of us at Universal Laser Systems, Inc. (ULS) would like to thank you for your purchase. Since 1988, the staff at ULS has been dedicated to total customer satisfaction. When you buy Universal you get more than a money making product, you get a team of talented, experienced, and enthusiastic people who are focused on your satisfaction. Our commitment is to help you be successful right now and in the future.

To begin with, we highly recommend that this entire manual be read before attempting to use the device. The manual includes important information about safety, assembly, use, and basic maintenance.

How To Get Help

Before contacting our Technical Support Department, make sure that you have read this entire manual as well as any other accompanying manuals included with your laser system.

Step 1:

Try to recreate the problem and write down the circumstances in which the problem occurred. Try to recall if the problem began all of a sudden, worsened over time, or began after you performed any recent maintenance. Also be prepared to describe all pertinent information about the computer being used such as graphics software, Universal Control Panel (UCP) software version, computer operating system and computer type, configuration, and accessories.

Step 2:

Make sure that you have the system serial number available. The serial number tag is located on the back of the machine, next to the exhaust port. We may not be able to assist you without this number.

Step 3:

Contact your local VersaLASER reseller. If possible, call from a telephone that is close to the VersaLASER so that it can be operated while speaking on the telephone.

Step 4:

If your local VersaLASER reseller cannot assist you and you would like to use our **FREE**, email based support system, log on to our website: www.ulsinc.com/versalaser/. Click on the "Contact Us" link, then click on the "Technical Support Request" link and follow the instructions.

Step 5:

If you are unable to obtain Internet access, you may contact our Technical Support Department at:

Universal Laser Systems, Inc.

Technical Support Department

16008 North 81st Street

Scottsdale, AZ 85260

Phone: 480-609-0297

Fax: 480-609-1203

M-F 8am – 5pm Arizona Time

support@ulsinc.com

Specifications

System Operating Environment Requirements (user provided)

	Models	
	VLS2.30	VLS3.50
Operating Environment	Well-ventilated office (recommended) or clean, light-duty manufacturing area	
Operating Temperature	50°F (10°C) to 95°F (35° C) capable 73°F (22°C) to 77°F (25° C) for best performance	
Storage Temperature	50°F (10°C) to 95°F (35° C)	
Operating Humidity	Non-condensing	
Electrical Power	110/230 VAC, 10/5A, Grounded	110/230 VAC, 10/5A, Grounded
Particulate/Odor Outside Ventilated Exhaust System	High-pressure vacuum blower capable of 150 CFM (cubic feet per minute) @ 6 inches static pressure (255m ³ /hr at 1.5kPa)	
Computer Requirement	Windows XP or Windows Vista (32-bit version only) Available USB 2.0 High Speed port	
Software Requirement	Any Windows based Graphics or CAD application	

System Specifications

Laser Safety	CO2 Laser, Interlocked Safety Enclosure = Class I Red Diode Pointer = Class IIIa	
Laser Source	10, 25 or 30 watt CO2 Laser	10, 25, 30,40, or 50 watt CO2 Laser
Cooling	Air Cooled	
Work Area	16" x 12" (406.4 x 304.8 mm)	24" x 12" (609.6 x 304.8 mm)
Printer Driver	Windows XP or Windows Vista (only)	
Hardware Interface	USB 2.0 High Speed port	
Dimensions	26"Wide x 25" Deep x 14"Height (660.4mm x 635mm x 355.6)	34"Wide x 25" Deep x 14"Height (863.6mm x 635mm x 355.6)
System Weight	System = 85 lbs. (38 kg)	System = 100–106 lbs. (45-48 kg)
Laser Cartridge Weight	10 Watt = 13 lbs (6kg) 25/30 Watt = 20 lbs (9 kg) 40 Watt = 23 lbs (10 kg) 50 Watt = 26 lbs (12 kg)	
Available Options	Cart, Integrated Air Cleaner, Rotary Fixture, Air Assist, Compressed Air, Cutting Table, Focus Lens Kits	

Specifications subject to change without notice

Table of Contents

Section 1 – Safety

Description of Appropriate Use	1-1
General Safety	1-1
Laser Safety	1-2
Safety Labels	1-2
EU Compliance (CE).....	1-5
FCC Compliance	1-6
Recycling.....	1-6

Section 2 – Installation

Establishing a Proper Operating Environment.....	2-1
Extracting Fumes and Particulates	2-1
Providing a Suitable Electrical Power Source.....	2-3
Software Installation and Operating System Requirements	2-3
Computer Requirements	2-3
The Software Installation CD-ROM	2-5
Recommended Software Programs	2-6
Configuring Your Graphics Software	2-7
Unpacking and Assembling the VersaLASER	2-11
Finalizing the Connections.....	2-12

Section 3 – Running Your First Job

Step 1 – Creating Your Artwork	3-1
Step 2 – Printing Your Artwork.....	3-1
Step 3 – Powering On the VersaLASER.....	3-2
Step 4 – Loading and Positioning Your Material.....	3-2
Step 5 – Running Your Job.....	3-2
Step 6 – Powering Off the VersaLASER.....	3-2

Section 4 – Operation

How it Works	4-1
The VersaLASER Keypad	4-1
The Universal Control Panel (UCP)	4-2
Printer Driver Controls.....	4-4
Manual Focus.....	4-5

Section 5 – Basic System Maintenance

Safety	5-1
Cleaning and Maintenance Supplies	5-1
Optics	5-2
Optics Handling Guidelines	5-2
Optics Cleaning Procedure.....	5-2
Accessing the Optics	5-2
#2 Mirror	5-3
#3 Mirror and Focus Lens.....	5-3
Beam Window.....	5-4
The Motion System	5-4
The Main Enclosure	5-5
Adjustments and Lubrication.....	5-5
Interlock Safety Check	5-5
Fuse Replacement.....	5-5
Cooling Fan Filters	5-6
Maintenance Schedule.....	5-6

Section 6 – Accessories

Cylindrical Object Rotary Accessory..... 6-1
Vector Cutting Accessory..... 6-6
Integrated Cart 6-8
Computer Controlled Air Cleaner / Cart..... 6-8
Computer Controlled Compressed Air Unit..... 6-11
Air Assist Cone..... 6-12
Air Assist Back Sweep 6-14